


PANEL1700FC

Studio LED Panel



USER MANUAL

- Be sure to read the USER MANUAL carefully before using this product.
- Be sure to keep the USER MANUAL properly for future needs.
- Use this product correctly when you can fully understand the User Manual

TABLE OF CONTENTS

1. Safety instruction	2.3
2. Technical specifications	4.5
3. How to set up lighting fixtures	5.6.7.8.9
3.1 Control Panel	5.6.7.8
3.2 Main Functions	8.9
4. DMX Channel	9.10.11.12.13
5. Troubleshooting	13.14
6. Fixture cleaning	14

Safety Instruction



WARNING

Please read the instructions carefully which includes important information about the installation, operation and maintenance.

Keep this manual as a basis for future consultation, and if you sell this product to other users, make sure they get this manual.

Pay attention to:

The equipment is well packaged when leaving the factory. Please follow the user manual. The machine failure caused by human reasons is not covered by the warranty.

- ☑ Before using the product, please open and check carefully to ensure that the lamps have no damage caused by transportation.
- ☑ Equipment is suitable for both indoor and outdoor use.
- ☑ The installation and operation of the fixture shall be carried out by the professionals.
- ☑ Don't let the children operate this fixture.
- ☑ Use safe ropes to fix the equipment, and hold the bottom when moving it.
- ☑ Equipment must be installed in a well-ventilated place, at least 50cm next to other plane items.
- ☑ Ensure that the air vents are unobstructed to avoid overheating during lamp operation.
- ☑ Before operation, ensure that the supply voltage matches the supply voltage required by the equipment.
- ☑ Please ground the conductor in case of electric shock..
- ☑ Do not operate lamps below 0°C or above 40°C.
- ☑ Do not connect the lamp directly to the dimming device.
- ☑ Do not place combustible items next to the lamps when operation to prevent fire risk.
- ☑ Before opening the fixture, please carefully check whether the power cord is damaged. If there is any damage, please replace it immediately.
- ☑ Avoid flammable liquid, water or metal and other conductive bodies into the lamp, to avoid electric shock or fire. If any foreign matter enters the lamp,

please cut off the power supply immediately.

- ☑ Avoid operating the lamps in a dirty and dusty environment, and clean and maintain the lamps regularly.
- ☑ Do not touch the wire when the lamp is running to prevent electric shock.
- ☑ Avoid the winding of the power cord with other wires.
- ☑ Disconnect the power supply before replacing the fuse. ☑ Use the same model when replacing the fuse.
- ☑ Do not open the lamp repeatedly.
- ☑ Please replace the lamp shell, lens or ultraviolet filter in time.
- ☑ No available parts inside the lamp, do not open the lamp shell without authorization.
- ☑ If the machine fails, please stop using immediately and check without electric power; Do not repair by yourself; It need help, please contact the most recent authorized sales / technology center.
- ☑ Please cut off the power supply when the lamp is not used for a long time or is repaired.
- ☑ When transporting it again, please use the original packing material.
- ☑ Do not look directly at the lamps during operation.
- ☑ Do not operate the lamp without a protective cover or a shell damage.

Install:

The lamp should be fixed on the fast lock hook to ensure the installation firmly to prevent the trembling slide during operation. And make sure it's connecting structure of the lamp can support 10 times weight of the lamp. Install the lamp with the one able to support 12 times its weight safety rope.

The installation of the equipment should be carried out by professionals, but also installed in the place that people can not touch or easy to touch.

1. Technical specifications

Input power supply: AC 100~240V, 50/60Hz

Power: 350W

Light source: 288pcs CW LED + 288pcs WW LED

Color temperature: 2800~6500K $\pm$ 100K

Beam angle: 110°

Optics:

CRI: $\geq$ 97

CQS: $\geq$ 96

TLCI: $\geq$ 97

Control:

Channel mode: 1.P1: CCT 8Bit 7CH
 2.P2: CCT 16Bit 10CH
 3.P3: FX 8Bit 13CH

Control protocol: DMX512, RDM,

Software upgrade: Update software via USB

Structure:

Display screen: 1.77 LCD display screen

Signal input/output: 5 pin XLR socket

Power socket: power connector input

Protection level: IP20


2.Main features:

PANEL 1700FC is used in various photography, television stations, conference rooms, large shopping malls, etc. It is widely used by its outstanding soft lighting characteristics . Powered by DC26V battery.

Size/Weight:


Dimensions: 737 * 382.5 * 173mm

Net weight: 11.8KG



3.How to set up the unit

control panel



V-port battery input: DC26V battery

Display:

Display function menu and selected function

Key:

CCT button

The CCT button enters color temperature mode, and use the CCT knob INT/SEC knob to scroll through the color temperature and brightness settings.

FX button:

Press the EFFECT button to enter the main scene interface Use the INT/SEC knob to scroll and select the scene mode.

Set button:

Press the Setting button to enter the main settings interface. Use the INT/SEC knob to scroll and select settings options.

MENU/LOCK button:

Short press the MENU/LOCK button to return to the previous page, long press the MENU/LOCK button to unlock and lock.

(INT/SEC) Encoder:


Select Encoder: I/S Function:

- Dimming settings
- Menu selection settings.

Menu Open: Use the I/S scroll menu to open submenus and set parameters.
Press the knob to open the submenu and confirm the settings.

CCT encoder:

- Color temperature setting
- Sub menu parameter selection settings.



DC switch: The switch for battery .

4.Main Menu:

CCT	0.0%-100.0% brightness	
	2800-6500K CCT	
EFF	Candle	Fire
	Fireworks	Paparazzi
	Strobe	TV
	Explosion	Welding
	Lightning	Cloud
SETUP		address: 001-512
		Lost: Hold/Delay/OFF
		DMX SW: ON/OFF
		RDM SW : ON/OFF
		Mode : P1: CCT 8Bit 7CH P2: CCT 16Bit 10CH P3: FX 8Bit 13CH
	DMX512	Terminal: ON/OFF
	FAN Setting	Off/Low /Auto/High/Full
	Language Setting	English/中文
	Dim Curve	Linear/Exponent/S Curve /Log/TV Curve
	Display Setting	Brightness : 1-10
		LCD Time: 10-60sec/ Always
		Rotation: 0 degree/180 degree
		Buzzer : ON/OFF
	Update	USB update
	Restore	Yes/No
	About	FW Ver : V1.1.4 T
		DMX Ver: V1.0.0
		RDM Ver: V1.0.0
		Serial : XXXXXX

5.DMX Channel table:

Mode 1: CCT, 8bit			
DMX Channel	Value	Percent	Function
1	0-255	0-100	Brightness: OFF->ON
2	0-255	0-100	CCT : 2800K-6500K
3			NONE
4 Notice: When the DMX signal is lost, the fan mode returns to the lighting menu settings.	0-9 10-57 58-105 106-153 154-201 181-250 251-255	0-3 4-22 23-41 42-60 61-78 79-97 99-100	Fan control: Use the fan mode settings in the menu Low speed mode Auto Mode High speed mode NONE Full speed Fan Off
5-7			Reserved

Mode 2: CCT, 16bit				
DMX Channel		Value	Percent	Function
HI	LO			
1	2	0-65536	0-100	Brightness: OFF->ON
3	4	0-65537	0-100	CCT: 2800K-6500K
5	6			NONE
7		0-9 10-57 58-105 106-153 154-201 181-250 251-255	0-3 4-22 23-41 42-60 61-78 79-97 99-100	Fan control: Use the fan mode settings in the menu Low speed mode Auto Mode High speed mode NONE Full speed Fan Off
8-10				Reserved

Mode 3: EFFECT, 8bit			
DMX Channel	Value	Percent	Function
1	0-255	0-100	Brightness: OFF->ON

2	0 – 9	0 – 4	Scene Selection
	10 – 19	5 – 7	NONE
	20 – 29	8 – 11	NONE
	30 – 39	12 – 15	Candle
	40 – 49	16 – 19	Cloud
	50 – 59	20 – 23	NONE
	60 – 69	24 – 27	NONE
	70 – 79	28 – 31	Fire
	80 – 89	32 – 35	Fireworks
	90 – 99	36 – 39	Strobe
	100 – 109	40 – 43	Lightning
	110 – 119	44 – 47	Paparazzi
	120 – 129	48 – 51	NONE
	130 – 139	52 – 55	TV
	140 – 149	56 – 58	Explosion
	150 – 159	59 – 62	None
	160 – 169	63 – 66	None
	170 – 179	67 – 70	Welding
	180 – 255	71 – 100	Reserved
3	0–255	0-100	Scene parameters 1 as the table below
4	0–255	0-100	Scene parameters 2 as the table below
5	0–255	0-100	Scene parameters 3 as the table below
6	0–255	0-100	Scene parameters 4 as the table below
7	0–255	0-100	Scene parameters 5 as the table below
8	0–255	0-100	Scene parameters 6 as the table below
9	0–255	0-100	Scene parameters 7 as the table below
10 Notice: When the DMX signal is lost, the fan mode returns to the lighting menu settings.。	0 – 9 10 – 57 58 – 105 106 – 153 154 – 201 202 – 249 251 – 255	0 – 3 4 – 22 23 – 41 42 – 60 61 – 78 79 – 97 99 – 100	Fan Control: Use the fan mode settings in the menu Low Speed mode Auto Mode High speed mode NONE Full speed Fan Off
11–13			Reserved

Mode 3: EFFECT, 8bit, Candle			
Scene parameters	Value	Percent	Function
1	0-84 85-170 171-255	0-33 34-66 67-100	CCT range is discontinuous, randomly generate the setting range 4000 → 4400 K 4400 → 4800 K 4800 → 5200 K
2	0-255	0-100	Speed Change 0 → 120 times/minute

Mode 3: EFFECT, 8bit,Cloud			
Scene parameters	Value	Percent	Function
1	0-255	0-100	Bias Paranoid values 0-50 Generate a new bias every 5 DMX values
2	0-127 128-255	0-50 51-100	Speed 2x slow speed → default speed Default speed → 2x faster

Mode 3: EFFECT, 8bit,Fire			
Scene parameters	Value	Percent	Function
1	0-84 85-170 171-255	0-33 34-66 67-100	CCT range is discontinuous, randomly generate the setting range 4000 → 4400 K 4400 → 4800 K 4800 → 5200 K
2	0-255	0-100	Speed Change 0 → 180 times/minute

Mode 3: EFFECT, 8bit, Fireworks			
Scene parameters	Value	Percent	Function
1	0-84 85-170 171-255	0-33 34-66 67-100	CCT range is discontinuous, randomly generate the setting range 2800 → 4000 K 4000 → 5300 K 5300 → 6500 K
2	0-255	0-100	Speed 10s-0.5s Fireworks interval

Mode 3: EFFECT, 8bit,Strobe			
Scene parameters	Value	Percent	Function
1	0-255	0-100	Speed Strobe 1 → 25 times/second
2	0-255	0-100	CCT CCT 2800K-6500K

Mode 3: EFFECT, 8bit,Lightning			
Scene parameters	Value	Percent	Function
1	0-254 255	0-99 100	Frequency 2 → 14 lightning settings Random
2	0-254 255	0-99 100	Speed 0 → 10 strobe/second Random
3	0-255	0-100	CCT CCT 2800K-6500K

Mode 3: EFFECT, 8bit, Paparazzi			
Scene parameters	Value	Percent	Function
1	0-255	0-100	Frequency Strobe6 → 120 times/minute
2	0-127 128-254	0-50 51-100	Type Modern Classics
3	0-255	0-100	CCT CCT 2800K-6500K

Mode 3: EFFECT, 8bit, TV			
Scene parameters	Value	Percent	Function
1	0-84 85-170 171-255	0-33 34-66 67-100	CCT range is discontinuous, randomly generate the setting range 4000 → 4400 K 4400 → 4800 K 4800 → 5200 K
2	0-255	0-100	Speed change4 → 24 times/minute

Mode 3: EFFECT, 8bit,Explosion			
Scene parameters	Value	Percent	Function
1	0-255	0-100	Reduction Reduction 4→ 0.5times per second
2	250-255	0-100	Trigger Manual (explosive intensity)
3	0-255	0-100	CCT CCT 2800K-6500K

Mode 3: EFFECT, 8bit,Welding			
Scene parameters	Value	Percent	Function
1	0-255	0-100	Speed Slow → Fast
2	0-255	0-100	Minimum value 0% → 75% Minimum value
3	0-255	0-100	CCT CCT 2800K-6500K

Troubleshooting

Following are a few common problems that may occur during operation.

Here are some suggestions for easy troubleshooting:

A. The fixture does not work, no light output, fan no work

1. Check the connection of power.
2. Measure the mains voltage on the main connector.
3. Check the power indicator

B. Not responding to DMX controller

1. DMX LED should be on. If not, check DMX connectors, cables to see if link properly.
2. If the DMX LED is on and no response to the channel, check the address settings and DMX polarity.
3. If you have intermittent DMX signal problems, check the pins on connectors or on PCB of the fixture or the previous one.
4. Try to use another DMX controller.
5. Check if the DMX cables run near or run alongside to high voltage cables that may cause damage or interference to DMX interface circuit.

C. Some fixtures don't respond to the easy controller

1. You may have a break in the DMX cabling.
2. Check the LED for the response of the master/ slave mode signal.

5.Fixture cleaning:

The cleaning of internal must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the fixture operates: damp, smoky or particularly dirty surrounding can cause greater accumulation of dirt on the fixture's optics.

Clean with soft cloth using normal glass cleaning fluid.

Always dry the parts carefully.

Clean the external optics at least every 20 days. Clean the internal optics at least every 20 days.